

TOOL CHART

TOOL	MARK & REVISION	OMEN SERIES		ESSENCE SOUL		SOUL SUPERFLY		SOUL SUPREME PRESENCE DRUID			DEFINITION			DOMINANCE		UNBERTONE	SUBMISSION	ZU/DL-103	ZU/DL-103R	
		I	I-B	I	I	II	I	I-B	I	I ^{II}	I ^{IV}	V	I ^{II}	III	IV	I	I	I	I ^{II}	I ^{II}
T-25 screwdriver (Wera 1767 #05031305002) 2009~present FRD.		●	●	●		●	●	●	●	●	●	●	●	●	●					
T-20 screwdriver (Wera 1767 #05031304002) some 2008~2009 FRD.		●		●	●				○	○		●	●							
Square #1 screwdriver (Wera 368 #05117682003) non-Radian tweeter lens.		●	●	●	●	●	●	●	●	●	●	●	●	●						
Square #2 screwdriver (Wera 368 #05117684003) some 2001~2009 FRD.						●			○	○		●								
Phillips #2 screwdriver (Wera 350 #05008720003).				●					●	●	●	●	●	●		●	●			
5mm Allen t-handle (Eklind 6" 64650) all Radian 850/950 tweeter lens.								●	○				●	●						
3mm Allen screwdriver (Wera 354 #05023110003) all ribbon tweeter network.				●																
3mm Allen or T-8 (Wera TX-8 #05028003003) for ZuB3 flange, amp, other.								●			●									
7/32 [5.5mm] (Proto 7/32 x 7/32 #J3314) wrench or socket for ZuB3 flange & amp.													●	●						
T-10 screwdriver (Wera 0528004) for backplates of of most 2012 and later.					○	●	●	●	○		●				●					
5/32" [T-25 or 4mm] Allen. Subwoofer driver.														●	●	●	●			
5/16" [8mm] Allen. Machined base.											●			●	●		●			
9/16" [14mm] open-end wrench for adjusting footers (3/8-16).		●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●			
5/64" [2mm] x .0157" [.40mm] thick, straight blade.																		●	●	
1/16" Allen. For machined knob set screws.													●	●		●	●			
Keyhole saw (Greenlee #301A) only needed for upgrade kit cabinet modification.										●	●	●								

FRD SHIPPED PAIR FASTENERS	
1/4-20 x 1-3/4" black oxide button head Allen drive (3/16" or T-25).	
1/4-20 stainless wingnuts.	

[Mk.] Mark = major platform change. There are no in the field upgrade options to move from one mark to the next.
 [Rev.] Revision = update within marked platform. In the field upgrade kits are made available.
 Mark is Roman numerical. Revision is alphabetical. Rev-A is assumed and never noted.
 Example of notation: Mk.III [Rev-B], III-B.

[●] = required for service.
 [○] = possibly needed as fastener changed mid run.